



# MJ-906S USER MANUAL


## ACCESSORY/STRUCTURE



### **HOW TO INSTALL**



## **HOW TO INSTALL BATTERY PACK**



#### **BATTERY INDICATOR**







#### **HOW TO RECHARGE**





#### **SWITCHING THE LIGHTING MODE**

Hold 1s power button to turn on/off


Modes Switch:


From bicycle light mode to E-bike light mode:

Long press power button for 8 seconds until it flashes.

From E-bike light mode to bicycle light mode:

Long press power button for 8 seconds until it lights constantly.









1s Hold 1 second

#### **LUMENS/RUN TIME**

#### Bike mode

BRIGHTNESS	DRL	/	/	
LUMENS 3145	35	/	/	/
h:min	35:30	/	/	/
CONSTANT	ECONOMICAL	LOW	MID	HIGH
LUMENS	600	1200	1600	2300
h:min	11:30	07:00	05:00	04:30
LUMENS	800	1800	2500	4500
h:min	10:30	05:30	04:30	04:00
FLASH	FLASH 1	FLASH 2		/
LUMENS	0-2300	0-600	/	/
h:min	06:30	18:30	/	/

#### E-bike mode

NIGHT	HIGH	MID	LOW	FLASH
LUMENS	4500	2500	1800	0-1800
DAY	DRL			
LUMENS	35	/	/	/

The data is tested in laboratory conditions, and the actual peformance can change riangle according to the environment.

#### **OPTIONAL PARTS**





Helmet mount

TTA front mount

\*Adaptable accessories (sold separately)

#### **M** WARNING





#### **IN WARRANTY**

The Magicshine lighting system is warrantied for 24 months from the date of purchase.

If you register the lighting system on the Magicshine website you will receive a bonus 6 month warranty.

Battery packs and AC adapters have a 6 month warranty, however, there is no bonus warranty available.

The warranty is limited to defects in material and workmanship on the lighting system itself, the battery pack and the AC adapter.

The warranty is only valid if the affected parts have not been tampered with and there is no intentional damage. Please keep your proof of purchase in a safe place. Proof of purchase must be presented in the event of any claim. Please contact the specialist retailer from whom you purchased the device for complaint or warranty claim.

Alternatively, you can send your complaint or claim directly to Magicshine at

Tel: (+86) 755-295 536 69 Fax: (+86)755-275 897 77

E-mail: support@magicshine.com (order from Magicshine.com online store)

service@magicshine.com (order from other sales channels)

In the event of a justified warranty claim and delivery of a replacement device, you will only be entitled to a model available when replacing. The manufacturer retains the right to make technical modifications.

















