

MOH 35 USER MANUAL

ACCESSORY/STRUCTURE





MOH 35





Headlamp strap




USB-C cable

Wire clip

Headlamp strap

FEATURES

1. White and red light , 60° angle adjustment.




2. Strap with reflective function.



3. High capacity 4000mAh battery pack, USB-C charging/discharging port.

- 4. Convenient USB-C charging, plug-and-charge feature.
- 5. IPX6 waterproof rate.

HOW TO ASSEMBLE



BUTTON FUNCTION

1. Long press the power button 0.5s to turn ON/OFF.

Power button -



2. Mode switching: with the lamp on, double click the power button to switch between white light mode and red light mode.

3. Single click to switch gears in the corresponding mode.

BATTERY INDICATOR

With the lamp off, click power button once to momentarily display battery status (light will shut down automatically after 3 seconds).







FLASHES GREEN ILLUMINA 74%-50% 1009

ILLUMINATES GREEN 100%-75%

HOW TO CHARGE& DISCHARGE



ILLUMINATES GREEN Fully charged




ILLUMINATES RED Discharge

FLASHES RED Lower power

MODE OPERATION

Mode memory: the light remains in the output setting it is switched OFF in.



LUMENS/RUN TIME

MODE	BRIGHTNESS	LOW	MID	HIGH	TURBO	SOS
		30	100	400	1000	/
	L h:min	62:00	13:24	08:12	02:06	/
8		5	50	100	/	/
	L h:min	240:00	60:00	18:30	/	/
8		5	/	100	/	100
	L h:min	230:00	/	10:00	/	/

NSI FL 1 STANDARD



1. LED: CREE XP-L2 V6 (white light)+XD-16 S2 (warm light)+XQ-E(red light)

2. Size: 53.8x32x40 mm





Do Not Look Directly Into Light Beam Or Shine Into Eyes Of Another.

EN WARRANTY

The Magicshine lighting system is warrantied for 24 months from the date of purchase.

If you register the lighting system on the Magicshine website you will receive a bonus 6 month warranty.

Battery packs and AC adapters have a 6 month warranty, however, there is no bonus warranty available.

The warranty is limited to defects in material and workmanship on the lighting system itself, the battery pack and the AC adapter.

The warranty is only valid if the affected parts have not been tampered with and there is no intentional damage. Please keep your proof of purchase in a safe place. Proof of purchase must be presented in the event of any claim. Please contact the specialist retailer from whom you purchased the device for complaint or warranty claim.

Alternatively, you can send your complaint or claim directly to Magicshine at

Tel: (+86) 755-295 536 69 Fax: (+86)755-275 897 77 E-mail: support@magicshine.com (order from Magicshine.com online store) service@magicshine.com (order from other sales channels)

In the event of a justified warranty claim and delivery of a replacement device, you will only be entitled to a model available when replacing. The manufacturer retains the right to make technical modifications.